


ASRIN TV STAND ASSEMBLY INSTRUCTIONS







Dear Customer,

- * The product you purchased has been thoroughly tested and inspected by us before being shipped to you.
- * However, even in this case, some parts may be damaged during transportation. If you encounter such a situation, please do not return the entire product. Request only the damaged part. When requesting the necessary part, please refer to the service card to identify the part accurately. The missing part will be sent to you as soon as possible.
- * Before starting assembly, check all parts and accessories that come out of the boxes according to the lists. After making sure that the parts and accessories are complete and intact, start assembly. Before starting assembly, clean each part with a damp cloth.
- * If you have purchased more than one product, proceed to the next product after assembling a single product to avoid confusion. Do not drag the products while moving them. Lift and disassemble the product and carry it with at least two people. Be sure to transport the product in its packaging when transporting it over long distances.
- * The surfaces of the furniture you have purchased are very easy to clean. Wiping with a damp, soapy cloth or other household cleaners is sufficient.
- Since furniture is affected by extreme heat, cold, and moisture, do not expose your furniture to these factors directly.
- * Do not use your furniture for purposes other than its intended use.

