




Multi-purpose cabinet




Left Side




Right Side




Middle Strut




**BOTTOM
TABLE**





**SABIT
RAF**




**TOP
TABLE**




**CYCLE
RACK
3x**




ACCESSORY LIST




3,5x18 SCREW




SHELF PIN




MINIFIX SHAFT



MINIFIX Nut






**FULL
CAMEL
HINGE**



Wooden Foot


1




Feet on guide marks as in the image
Mount it.




2





Insert and fix the minifix
shafts into the previously
prepared guide holes.



8 Quantity



3






Place the center upright, fixed shelf
and right side on the minifix shafts
and secure by tightening the
minifix nut.



4 Quantity

4





Left side Fix the hinges on the
guide marks prepared for the
hinges.



3,5x18 Screw

5






Place the right side and left side
on the minifix shafts and secure
by tightening the minifix nut.




6 Quantity

6



Insert the backs into the
channels. Then insert the
H profile and fix it with the
backrest stabilizer.









Place the top plate on the minifix shafts and secure it by tightening the minifix nut.




6 Quantity

Before placing the mobile shelf, mount the shelf pins on the slots as shown in the image.






Mount the hinge strikes on the tracks as shown in the image.



Place and secure the hinges as shown in the image.

You can adjust the asymmetrical stance between the lids by loosening the screw, positioning it in the desired position and then tightening it.



The distance between the lids can be adjusted by loosening this screw, positioning it in the desired position and then tightening it.

If you are satisfied with our service, you can honor us with your positive ratings and comments and contribute to other customers to shop with us. you can be found.